





## INSTALLATION

### EIFS facade

- It must be checked that the substrate wall shows an even surface, and that there is no mortar projection from bricks joints.
- DANOPREN® FS boards are installed from the bottom to the top of the wall, in horizontal rows and staggered in successive rows.
- The boards must be fixed to the substrate wall with adhesive on more than 80% of the surface or mechanical fasteners and adhesive.
- The boards must show tight joints, avoiding they may get filled with adhesive.
- The edges of the DANOPREN FS boards should not be aligned with the windows edges.
- By the corners of every wall section forming the building facades, complete or half-sized DANOPREN FS boards must be installed, never smaller pieces.

## STORAGE AND PRESERVATION

- Do not expose to temperatures exceeding 75 °C.
- They must be protected from direct sunlight during storage for long periods of time.
- They can be stored outdoors, unaffected by rain, snow or ice.

## COMPATIBLE SOLUTIONS

